Glaze Application Guide

Works best with Zinc free celadon glaze



Recommended Method
Brush-On Glaze

For the smoothest glaze coverage,
Apply the first coat of glaze with a brush. **Allow the first coat to dry completely**. Apply a second coat evenly.

If applying multiple coats results in the glaze becoming too thick, dilute the glaze with up to 50% water before applying additional coats.

Best Results: Spray Glaze

Spraying glaze provides the most even and consistent glaze application





Dipping Glaze

Oil-based underglaze marker areas may **resist glaze** during dipping.